


PEC-DEC INSTRUCTIONS







PEC DEC BACK REST AND SEAT ASSEMBLY INSTRUCTIONS

ASK YOUR ASSISTANT TO HOLD THE BACKREST PAD SEAT AT THE APPROXIMATE HEIGHT YOU WANT THE SEAT LOCATED. LOCATE THE U-SHAPED MOUNTING BRACKETS OVER THE SPINE AS SHOWN AND BOLT TO THE SEAT BRACKETS USING 3/8 X 1 BOLTS, WASHERS, AND MUTS. AFTER INSTALLING BEARING HOUSING AND UPPER ARMS, TEST UNIT FOR SEAT HEIGHT AND ADJUST AS NEEDED.